

HEAT METERING UNITS

C ←BUS

UCR 668 C1 Eng.



- **Measures consumption using the compensated hours method (UNI / TR 11388)**
- **14 inputs for metering times in use:**
 - Total metering of effective and compensated hours
 - Seasonal metering of effective and compensated hours
- **Historic recording of a year's metering**
- **On-Off control plant pump in relation to plant demands**
- **Control plant valve for boosting by manual control**
- **Communication systems:**
 - C-Bus for telemanagement;
- **Power supply 230 V~; DIN rail mounting**

1. APPLICATION

UCR 668 is a microprocessor-based device for metering the consumptions of individual consumers (max 14) in central heating plants:


- Vertical distribution with a shut-off valve for each radiator;
- Horizontal distribution with a zone valve for each consumer.

2. FUNCTIONS

The main functions are:


- Metering operating times as:
 - total effective and seasonal hours;
 - hours compensated in relation to total and seasonal flow temperature.
- Recording of events (tests, tampering or faults) of the flat-located control units (ICS 6..) :
 - date and time of start event for each local command unit;
 - date and time of end event for each local command unit.
- Stored in a data logger all the recordings made for a year.
- Auxiliary On-Off switch to control plant according to heat demand from flats.
- Control opening valve for compensated by boosting by manual control.
- Input to stop metering (pump idle or fault in boiler plant).
- Control for external signalling of fault in the local control units.
- Alarm for short or open detector circuit and for fault in controllers, etc.
- Simulation of operation for testing electrical connections when commissioning.
- Option of connecting in C-Bus for telemanagement by central PC and/or local PCs.

3. FACIA



- | | |
|--------------------------|-------------------------|
| 1 – Alphanumeric display | 6 – Block metering |
| 2 – + and – keys | 7 – Fault metering |
| 3 – ← and → keys | 8 – Timer alarm |
| Warning LEDs : | 9 – Measurements alarms |
| 4 – Boosting heating | 10 – Unit fault alarm |
| 5 – Heating pump | |

4. OVERALL DIMENSIONS



- | |
|--|
| 1 – Protective cover for electronic components |
| 2 – Base with transformer, relay and terminal blocks |
| 3 – Screws for securing base and cover |
| 4 – DIN rail securing elements |
| 5 – DIN rail release lever |

5. TECHNICAL DATA (default values in bold type)

• **Electrical**

Power supply	230 V~ ± 10%
Frequency	50 ... 60 Hz
Consumption	5 VA
Protection	IP40
Radio disturbances	VDE0875/0871
Vibration test	with 2g (DIN 40 046)
Voltage-free output contacts:	
Maximum switched voltage	250 V~
Maximum switched current	5 (1) A
Construction standards	Italian Electrotech. Committee (CEI)
Data storage in memory	5 years
Software	Class A

• **Mechanical**

Case	DIN 6E module
Mounting	on DIN 35 rail
Materials:	
Base	NYLON
Cover	ABS

Ambient temperature:

Operating	0 ... 45 °C
Storage	- 25 ... + 60 °C
Ambient humidity	Class F DIN 40040
Weight	0.5 kg

• **Measurement ranges**

Temperature flow heating	0 ... 99.5 °C
Number metering inputs	1...14
Total metering heating	99,999 hours
Partial metering heating	9,999 hours

• **Setting ranges**

Maximum flow temperature	1 ... 80 ... 99 °C
Minimum flow temperature	1 ... 25 ... 99 °C
Boosting time heating	0 ... 1 ... 99 hours
Delay switching off pump	0 ... 30 ... 240 min

• **Setting ranges telemanagement** (setting by PC)

Telemanagement password	0 ... 65535
Attempts to send alarms	1 ... 5 ... 255
Interval between alarm calls	2 ... 10 ... 255 min


In the presence of electrical disturbances the output controls of the controller may change status but this will automatically return to normal.

6. ACCESSORIES


No.	Description	Type	Sensing element	Code	Data sheet
1	Immersion-type flow temperature detector (0 ... 99 °C)	SIH 010	NTC 10 kΩ	B1	-

7. WIRING DIAGRAMS

7.1 Wiring diagram with UCR 668 connected to ICS 6... ("THERMSHARE" system)



7.1 Wiring diagram with UCR 668 connected directly to the end of run of the zone valves (valve open = switch closed)



8. WIRING

Proceed as follows :

- Separate base and cover
- Mount base on DIN rail and check that the securing elements (4.4) hold it tightly.
- Eseguire i collegamenti elettrici come da schema rispettando le normative vigenti e usando conduttori da :
 - two cables minimum 1.5 mm² cross section for power supply from 230 V~ domestic supply.
 - two cables minimum 0.5 mm² cross section for site flow sensor..
 - one cable 1.5 mm² cross section for connection to earth consisting of any metallic pipe of the heating site (dotted line), to be used only if electrical continuity from the heating site to earth is guaranteed.
 - one cable for upper floors of building 2 x 1.5 mm² minimum cross section (for distances of 1 to 50 metres) and 2 x 2.5 mm² cross section (for distances of 50 to 100 metres) deriving from terminals L/N or 0/24 volts towards the ICS 6... devices control unit to the UCR or UCA units, or directly from the thermostats or from the end-of-runs of the zone valves.
 - one cable 1.5 mm² minimum cross section (for distances from 1 to 50 meters), and 2 x 2.5 mm² cross section (for distances of 50 to 100 metres) deriving from the earth terminal "D" of the ICS 6.. control unit.
 - 1 to 14 cables 0.75 mm² minimum cross section (for distances from 1 to 50 meters); or a cable 1.5 mm² cross section for distances from 50 to 100 meters. Connections from the ICS 6....
 - For C-Bus refer to Technical Data Sheet T 021.
- Switch on power (230 V~) and check its presence at terminals L and N.
- Switch off power, replace cover on base/terminal block and secure it with the four screws provided (4.3).

To facilitate the calculation of the total power supply or for groups, see the table in section 8.1.

You are advised not to insert more than two cables in a single terminal of the controller and, if necessary, to use external terminals..

8.1 Table of cable cross-sections for THERMSHARE system

Description	Power supply terminals	Controllers	CROSS-SECTION Distance from 1 to 50 meters	CROSS-SECTION Distance > 50 meters
Cable rising to floors	Power supply 24 V or 230 V~ - Terminals L/N or 0/24 ~	From UCR 668 to ICS ...	1.5 mm ²	2.5 mm ²
System earth cable	Earth - D Terminals	From UCR 668 to ICS ...	1.5 mm ²	2.5 mm ²
Cable for metering unit	Signalling metering pulses Terminals E from 1 to 14 or from total number of users or zones	From UCR 668 to ICS ...	0.75 mm ²	1.5 mm ²

8.2 Table for sizing of transformers for THERMSHARE system

Example: 14 users; for each user 1 ICS 618 + 9 CDR 061 making a total of 10 devices

Number user devices	Unit absorption devices VA	Total absorption per user	Number users	Total absorption of site VA
10	x 3	= 30	x 14	= 420

9. SITING CONTROLLERS

9.1 Metering unit

The metering unit must be sited in a dry location that respects the relevant ambiantal conditions given under Technical Data. If sited in a location classified as "Hazardous" it must be installed in a cabinet for electrical equipment constructed according to the current regulations for the class of danger involved. The metering unit can be installed on a DIN rail or in DIN modular units. If possible it should be installed in a space in the block serving all the flats (e.g. utility room near the boiler plant).

9.2 Flow temperature detector B1

With the plant pump on flow, the detector should be installed downstream of the pump; if the pump is on the return it should be installed at least 1.5 meters downstream of the control valve.

10. COMMUNICATION


10.1 C-Bus communication for Telemangement (for details please see Data Sheet T 021)

By means of the C-Bus output UCR 668 can be telemanged - two-way communication of data with one or more local PCs and/or a remote central control via telephone land lines.

From the PC(s) you can :

- see displayed and/or modify the data and values set on the display pages of the controller and the configuration data dedicated exclusively to telemangement (see "Technical Data");
- receive alarms coming from the plant;
- read the measurements of the temperature detectors;
- read all the values recorded by the controller (partial meterings, total meterings, recordings of events, etc).

10.2 C-Bus electrical connections



10.3 Address for telemangement

21.7

Address :	-
Group :	-

Under telemangement, the controllers, in order to be identified by the central PC and/or by the local PCs, must have a progressive address number.

If required, the controllers can be organized into groups according to certain shared characteristics (e.g. geographical location, type of building e.g. school, hospital).

Note:

When telemangement is not scheduled, leave the address in memory (-).

To cancel the values keep + and - keys pressed at the same time.

10.4 Sending alarms


21.6

Send Alarms :	NO
PassWTeleman :	NO

- **Send alarms :** NO = alarms not sent.
YES = alarms sent to central PC and shown by momentary appearance of word "ALARM" on display
- **PassWTeleman :** NO = password not entered.
YES = password enabled.

11. EXAMPLE OF INSTALLATIONS

11.1 "THERMSHARE": Installation with rising columns and one-wire control radiator valves.



Configuration of UCR 668 for the application described above.

- 21.2


1) **Flat number**
Fr:001 to:004 Numbering of flats connected (remember that for each UCR 668 up to 14 can be connected). Warning! This numbering has to correspond to the respective flat codes.
- 21.3

2) **Input meters CODED** UCR 668 connected to a control unit ICS 6.. from which it receives coded metering signals.
- 21.4

3) **Flow T detector CONNECTED** Detector B1 connected to flow of heating plant.
- 20.6

4) **Aux : AUTOMATIC**
DelayOn:xxOff:xx Plant pump "M" is controlled automatically by UCR 668 according to heat demand from flats.

11.2 TRADITIONAL ZONE INSTALLATION with local control by thermostat and centralized metering



Configuration of UCR 668 for the application described above.

- 21.2

1) **Flat number**
Fr: 001 to: 004

Numbering of flats connected (remember that for each UCR 668 up to 14 can be connected). Warning! This numbering has to correspond to the respective flat codes.
- 21.3

2) **Input meters**
ON-OFF

UCR 668 connected directly to room thermostats from which it receives On-Off metering signals.
- 21.4


3) **Flow T detector**
CONNECTED

Detector B1 connected to flow of heating plant. .
- 20.6

4) **Aux : AUTOMATIC**
DelayOn: xxOff: xx

Plant pump "M" is controlled automatically by UCR 668 according to heat demand from flats.

11.3 TRADITIONAL ZONED PLANT WITH SAFETY CONTROL



Configuration of UCR 668 for the application described above.

- 21.2

1) **Flat number**
Fr:001 to:004

Numbering of flats connected (remember that for each UCR 668 up to 14 can be connected). Warning! This numbering has to correspond to the respective flat codes.
- 21.3

2) **Input meters CODED**

UCR 668 connected to ICS.18 control unit from which it receives coded metering signals.
- 21.4

3) **Flow T detector CONNECTED**


Detector B1 connected to flow of heating plant.
- 20.6

4) **Aux : AUTOMATIC**
DelayOn:xxOff:xx

Plant pump "M" is controlled automatically by UCR 668 according to heat demand from flats.

11.4 TRADITIONAL ZONED PLANT WITH SAFETY CONTROL

siting switchboards below stairs/in cellar or in boiler house



Configuration of UCR 668 for the application described above.

- 21.2

1) **Flat number**
Fr: 001 to: 004

Numbering of flats connected (remember that for each UCR 668 up to 14 can be connected). Warning! This numbering has to correspond to the respective flat codes.
- 21.3

2) **Input meters**
CODED

UCR 668 connected to ICS.18 control unit from which it receives coded metering signals.
- 21.4

3) **Flow T detector**
CONNECTED

Detector B1 connected to flow of heating plant.
- 20.6

4) **Aux : AUTOMATIC**
DelayOn: xxOff: xx

Plant pump "M" is controlled automatically by UCR 668 according to heat demand from flats.

12. OPERATION

UCR 668 is a metering unit that measures heat consumption so that its cost can be shared among 14 zones.

12.1 Flat code

This is the code on which is based the whole system of metering and allocation of costs.

If this number is not correct all subsequent calculations will be affected so it is essential that no errors are made when assigning this flat or zone code.

In the "PREPARATORY WORK FORM", page 2, point 1, the significance of "flat or zone code" is explained in detail.

Since the metering unit can handle a maximum of 14 flats or zones (there are 14 inputs E1...E14) it is necessary to use more than one UCR 668 when the number of flats or zones exceeds this number. In this event, it is necessary, for each UCR 668, to enter the first and last code numbers of the flats connected to it so as to create a corresponding readout on the display.

21.2

Flat code
Fr:xxx to:xxx

Example: three UCR 668 units with a total of 32 flats:

1st Unit; Flats from No.1 to No.14 21.2
Flat code
Fr:001 to:014

Flat 1 : connected to D-E1; Flat 2: connected to D-E2 ; ; Flat. 14 : connected to D-E14

2nd unit; Flats from No.15 to No. 28 21.2
Flat code
Fr:015 to:028

Flat. 15 : connected to D-E1 ; Flat. 16 : connected to D-E2 ;; Flat. 28 : connected to D-E14

3rd Unit : Flats from No. 29 to No. 32 21.2
Flat code
Fr:029 to:032

Flat 29 : connected to D-E1 ; Flat 30 : connected to D-E2 ; Flat 31 : connected to D-E3 ; Flat 32 : connected to D-E4.

12.2 Method of metering

UCR 668 is able to meter:

- **"HEAT CONSUMPTION"** :also called in standards seasonal "compensated hours" after the season start date set as desired, and totals, for "Thermshare" flats or radiators. Heat consumption is calculated in the following way:

It is first necessary to establish 20.3
Design flow temp : 80.0 the design flow temperature is the

temperature which the radiators must reach when the outside temperature is the design minimum. In Milan, for example, the minimum outside temperature is - 5°C and the design flow for radiators is 80°C; if the minimum were different a different value would be set.

Even if the value set is not exact, its influence on the total calculation is small because this value is the same for all the flats.

Next it is necessary to establish: 20.4
Flow temperature Minimum Off : 25.0 this Minimum flow "Off" temp. is the tempe-

rature at which the radiators give out practically no heat to the room.

In this example the minimum flow temperature is set at 25°C, a reasonable value below which the radiators no longer give out heat.

The calorie consumption (**Cc**) is obtained as follows:

$$C_c = \text{time On} \times \frac{\text{actual flow temperature} - 25}{80 - 25}$$

time On = actual time in which the thermostat in the flat calls for heat;

actual flow temp. = flow temperature of plant (radiators) measured by detector B1

Example:

When temperature B1 is equal to or above 80 °C

1 hour of metering = 1 hour compensated


When temperature B1 is equal to or below 25°C

1 hour of metering = 0 hours compensated

When temperature B1 is equal to 52.5°C

1 hour of metering = 1/2 hour compensated

The graph of this formula is :



In practice, at the end of the season, the heat consumption is equal to all the hours in which the heating plant of the single flat has been On (thermostat On), moment by moment calculated on the thermal power emitted by the radiators: it is a coefficient proportional to the kCal consumed.

- **"HOURLY CONSUMPTION"**: for "Thermshare" flats or radiators; a total is made of the hours in which the thermostat of the single flat has called for heat during the whole season. It is the old system of an hour meter in zoned plants. This information serves also to give an idea of the true occupation figure for the flat used as a second home.
- **CENTRALISED "HEAT CONSUMPTION" AND "HOURLY CONSUMPTION"** : these are the same data just illustrated but referring to flats and radiators that remain centralized (see "Specific system technique"). In practice, these values are calculated in the same way as the previous ones but assuming that the thermostat always calls for heat (always On), as in fact happens with centralised flats or radiators. This information is important for allocating heating expenses when not all the flat occupiers participate in "Thermshare".

12.3 Available readings

17.3

Flat : xxx
Heat : xxxx.x

17.4

Flat Central htg
Hours : xxxx.x

17.5

Flat : xxx
Heat : xxxx.x

17.6

Flat Central htg
Hours : xxxx.x

18.1

Flat .xxx : On
C : xxxxx h : xxxxx

18.2

Flat Central htg
C : xxxxx h : xxxxx

• **Accessible to all without the use of access keynumber - partial (seasonal) metering**

- Flat xxx = user code.
- Heat : xxxx.x = seasonal heat consumption (compensated hours).
- Heat : xxxx.x = seasonal heat consumption (compensated hours) for radiators or flats that have remained with central heating.

- Flat xxx = user code.
- Hours : xxxx = effective seasonal operating hours.

- Hours : xxxx.x = effective seasonal operating hours for radiators or flats that have remained with central heating.

• **Accessible only using access keynumber – total metering (multi-seasonal)**

- Flat xxx = user code.
- On ; Off; Fault = operating status of user.
- C : xxxxx = total hours of compensated operation (or heat consumption).
- h : xxxxx = total effective operating hours.

- C : xxxxx = total hours of compensated operation (or heat consumption).
- h : xxxxx = total effective operating hours.

12.4 Stop metering

20.7

Stop metering :
EXCLUDED

By using the "F" switch (e.g. switching off or lockout pump) it is possible to stop all the metering using the following procedure:

- Stop metering : EXCLUDED : Stop unused meterings.
- SWITCH OPEN : stop metering with switch open (LED 3.6 lit).
- SWITCH CLOSED : stop metering with switch closed (LED 3.6 lit).

12.5 Control plant pump

20.5

Auxiliary switch
NORMALLY OPEN

- Auxiliary switch : NORMALLY CLOSED = switch opened when auxiliary output On.
- NORMALLY OPEN = switch closed when auxiliary output On.

20.6

Aux : AUTOMATIC
DelayOn : xx Off : xx

- Aux : ALWAYS ON = auxiliary always On;
- AUTOMATIC = auxiliary On when at least one of flats or zones calls for heat: optimisation of use of pump and/or boiler.
- DelayOn : xx = Delay time at startup.
- DelayOff : xx = Delay time at shutdown.

Warning: both when the auxiliary control is "ALWAYS ON" and "AUTOMATIC" it is advisable for the heating plant to be equipped with a balancing control system so that it keeps constant the pressure downstream of the pump independently of the water flow.

12.6 Boosting heating

20.8

Boosting heating
for hours : xx

By pressing for a few seconds one of the push-button switches (k1...Kn) connected in parallel (M-B2) it is possible, by means of output relay 5-6-7, to open fully the centralised control valve for a pre-determined time (= xx).

This function permits increasing the plant flow temperature to speed up heating after a long period of absence from the flat, and is mainly used for the holiday homes in the mountains.

13. CONFIGURATION

21.3

**Input meters
CODED**

Type of communication with the flats or zones; choice between:

- CODED : used in the "Thermshare" system; signals coming from ICS 6.. control units; The ICS 6.. units send special codes to the UCR 668 to communicate: if the unit calls for heat; does not call for heat; tampering or malfunctioning; thereby continuously monitoring the status of each single flat.
- ON - OFF: signals coming from simple voltage-free switches (e.g. thermostat or end-of-run zone valve).

21.4

**Flow T detector
CONNECTED**

Choice between:

- CONNECTED : the B1 detector (flow temperature) is connected so that heat consumption can be calculated.
- NOT CONNECTED : the B1 detector is not used and so the heat consumption cannot be calculated: the system will measure and indicate only the hourly consumption;

21.8

**Various alarms
- 2 7 8**

To enable the alarms, using + and - keys replace the dash with the number 1 and 2.

When the number flashes = alarm triggered

The effect of the alarm situations is delayed by about a minute

Type of alarm, reasons and effects:

- 1 = plant flow detector, to be enabled only when detector B1 is connected .
 - when there is a short or open detector circuit
 - LED "°C" 3.9 is lit and, during the whole time in which detector is faulty, the metering of the heat consumption is considered to be 50% (mean seasonal value).
- 2 = fault or tampering in flat:
 - this type of alarm can be used only if the metering signals come from an ICS 6.. control unit since this unit is able to send a fault or tampering signal.
 - Can be caused by:
 - power failure (min. 2 minutes) or breakage of internal transformer;
 - no connections to valve actuators (min. 2 minutes) :
 - general fault or tampering with electronic components or cables (e.g. attempted burglary).
 - LED 3.7 is lit and metering is stopped in the flat with alarm status.
 - UCR 668 closes switch 1-2 to activate an external alarm signal (optional) and memorizes data and start and end times of fault.
- 7 = memory – *cannot be disabled*
 - when principal memory of system signals meaningless values;
 - LED 3.9 lit: the memory of meter concerned has to be reset.
- 8 = internal clock – *cannot be disabled*
 - when clock shows meaningless values;
 - LED 3.8 lit.

13.1 Access code

21.9

**Access code
- - - -**

Choice and enabling of access code which prevents use of + and - keys and consequently any changes being made to the data.

Enter a code of four characters (alphanumeric) :

- with ← and → keys position cursor;
- with + and - keys replace each dash with a character.

When the code is different from "- - - -", if + or - keys are pressed, on the display appears the request to enter the access code. Only after having entered the exact code can you use the + and - keys. If for 15 minutes no key is pressed the protection is automatically re-activated. It is essential always to enter the access code in order to protect the settings and the configurations from tampering which would compromise the meter readings.

13.2 Name of plant site

21.1

**Name plant site
- - - - -**

Entering name of plant site; this appears on first page of display 17.1.

Each dash can be replaced, using + and - keys, by a letter of the alphabet (A...Z) or by a number (0...9). The → key serves to position the cursor .

13.3 Start of a new season (cancelling of partial meter readings of previous season)

17.2

New data after
xx/xx/xxxx

Establishes the date from which a new heating season starts and from which start the new partial meter readings, cancelling the partial readings of the previous season and the whole of the "RECORD EVENTS".

xx.xx.xxxx = day and month and year on which the new *heating season* starts.

Procedure for starting a new season:

17.9

Start new
season? NO ->

- NO = do not wish start a new metering season.
- YES = wish to start a new metering season, after which appears:

17.10

Enter Access
Code: - - - -

- - - - = enter Access Code set in the display. 21.9
Access Code
- - - -, and then follow the instructions on

17.11

Everything read
carefully? NO->

- enter YES and then press → key if you want to proceed, then:

17.12

Confirm start
season ? NO ->

- enter YES and then press → key to start new season:

17.13

New season
starting...

17.14

New season
started... ->

press → key to exit this display page.

13.4 Summer time

20.2

BST
Fr: - - . - - to: - - . - -

UCR 668 changes automatically the present time according to the British Summer Time (BST) period.

- Fr: - - . - - = enter the date of the last Sunday in March: the clock automatically goes forward one hour.

- to: - - . - - = enter the date of the last Saturday in October: the clock automatically goes back one hour..

To cancel the period keep + and - keys pressed at the same time.

14. RECORDERS

UCR 668 incorporates :

- a memory space available for recording events taking place in each flat or zone connected and events regarding the UCR 668 controller itself.

All the recordings are cancelled as soon as the new season starts so that new recordings refer only to the new season.

- a memory space dedicated to the internal data logger.

14.1 Recording of tampering or faults in individual flats or zones only if served by ICS 6..

21.3

Input meters
CODED

- Remember that Input meters
CODED has to be set on "CODED".
Whenever there are: tamperings, faults, breaks in the cables, short circuits in the connections between ICS 6.. and UCR 668; or when there is tampering or a fault in the flat in the connections between ICS 6.. and radiators; or when ICS 6.. is made to operate in "test" mode by a sustained pressing of the "Test" button (see ICS 6.. Data Sheet), UCR 668 makes a recording, as follows:

19.1

Flat xxx Fault x
12.18 of 10.02.99

- Flat. xxx = code of flat or zone
- Fault x = progressive number of event (max 3), of tampering, etc.
- 12.18 of 10.02.99 = time and date when ICS 6.. made test and found fault.

19.2

Flat xxx EndEv x
12.18 of 10.02.99

- Flat. xxx = code of flat or zone
- End Ev. x = progressive number of end of event (max. 3).
- 12.18 of 10.02.99 = time and date when ICS 6.. made test and found fault had ended.

• Each new recording cancels the oldest one.

14.2 Recording of events in each single flat or zone, if not serviced by ICS 6.. (e.g. traditional zoned plants)

21.3

Input meters
ON-OFF

- We recall that has to be set on "On-Off" (thermostat or valve switch).
- Each time the metering signals change state UCR 668 records:

19.1

Flat xxx On x
12.18 on 10.02.99

- Flat xxx = code of flat or zone.
- On x = progressive number of start "On" state (max 3).
- 12.18 on 10.02.99 = time and date of the event.

19.2

Flat xxx Off x
12.18 on 10.02.99

- Flat xxx = code of flat or zone
- Off x = progressive number of start "Off" state (max 3).
- 12.18 on 10.02.99 = time and date of the event.

14.3 Recording time and date of charging UCR 668

With these data it is possible to return to the exact periods in which UCR 668 was unable to carry out the metering because it was switched off for maintenance or on account of tampering. If the hours switched off are few in relation to those over the entire season, this does not have any relevant effect on the allocation of metered costs; otherwise it is necessary to bear in mind:

19.3

On : xx Hours : xxxx
12.18 of 10.02.99

- On : xx = progressive number of times UCR 668 is switched on 12.18 of 10.02.03 (max. 16) after being switched off.
- Hours : xxxx = total time in hours of the period in which UCR 668 has remained switched on, from the event of the first switching on until the moment in which the reading is taken. These hours and events are cancelled at the moment in which the new season starts.
- 12.18 of 10.02.99 = time and date of the event.

14.4 Historic recording

21.5

Recording
EACH WEEK

UCR 668 incorporates a data logger that permits making 52 recordings. The recorder is of the type "First in - first out", that is, with each new recording the oldest recording is cancelled. This data logger is always available in the memory of UCR 668 and can be displayed when UCR 668 is read with a computer.

15. TESTING AT COMMISSIONING

15.1 Testing electrical connections in the boiler plant

Testing to be carried out when installation, electrical wiring and configuration have been completed and tested.

With + and - keys select :

- Output: BOOSTING
AUX
FAULT
- Status : - OFF = Output off.
- ON = Output on.

22.1

Output : BOOSTING
Status : OFF

Check that the relative components respond correctly to the controls.


15.2 Testing connections to the flats

After having checked the electrical connections to UCR 668 in the boiler plant it is necessary to check the wiring from UCR 668 to the flats.

First, UCR 668 has to be configured with the correct codes for flats or zones (see 12.1 "Flat code"). **Before proceeding make absolutely sure that the instructions in 12.1 have been carried out and checked.**


There are two methods of testing according to whether UCR 668 is connected to the flats or zones with ICS 6.. control unit or with On-Off controls (e.g. thermostats).

• **Inputs to meters coming from ICS 6..**



Check that the configuration of UCR 668 is adapted to receive coded signals. At this point you can make a first check, after UCR 668 has been switched on for at least three minutes:

- if the LED "METERING - FAULT" (3.7) does not light, this means that all the ICS 6.. are at least connected to UCR 668;
- if the LED "METERING - FAULT" (3.7) lights, this means that one or more ICS 6.. are not connected, or that numbers of users who do not exist have been entered on UCR 668. Go to the menu page "TOTAL METERING", scan the metering pages of all the flats, take note of those indicating a flashing "FAULT" and check the relative connections.





When the checks have been completed and any corrections made, after about two minutes, the "METERING - FAULT" LED (3.7) should switch off.

Re-check that in all the metering pages the word "FAULT" disappears and if replaced by the words "ON" or "OFF" according to the control signal sent by the ICS 6... .

Having checked in this way that all the ICS 6.. are connected to UCR 668, you must then ensure that each of these is connected to its respective input; that is, that flat or zone codes correspond to the actual flats and zones.

You must check that, although all the wires have been connected, there are no switched connections (e.g. so that Mr Brown would pay Mr White's bill and vice versa) To avoid having to go continually up and down the stairs, (between the flats and the boiler room) in order to check the connections one wire at a time, or remove one ICS 6..unit at a time and check on UCR 668 the corresponding fault at the relative flat, UCR 668 has its procedure already programmed internally. This procedure is based on the use of the menu "RECORD EVENTS" :

- Synchronise your watch with the UCR 668 clock.
- Go to the first flat or zone and keep pressed the "TEST" button on ICS 6.. until a test cycle starts (see ICS 6.. data sheet); make a note of the exact time this operation was carried out referring it to the flat or zone code. Wait about two minutes before carrying out the same procedure in the second flat, and continue in this way.
- When the above operations have been completed for all the flats or zones, return to the UCR 668 and scroll to the menu page "RECORD EVENTS". The "TEST" function on the ICS 6.. units triggers, for each flat or zone, a recording of start fault and one for end fault on UCR 668.




The time of the "FAULT" in relation to the flat code must be about 2 minutes later than that signalled.

The time of "End F" (end of fault) must be about 2 minutes plus 20 seconds per radiator, later than that just indicated (start of fault).

It is clear that in this way you can discover if any flats have been mistakenly exchanged for one another and, if so, which ones.



• **Input meters deriving from switches (thermostats or zone valves)**

Check that the configuration of UCR 668




is adapted to receive signals from open or closed switches.

The procedure is similar to the previous one: instead of using, for each flat or zone, the "TEST" button on ICS 6.., you must switch on (or off) for at least three minutes and then switch off (or on) the plant (e.g. with the thermostat), wait two minutes for each flat, and then go to the UCR 668.



16. SEQUENCE OF DISPLAY PAGES (the data and functions are the factory settings)



⬅ ➡ Keys for scrolling pages on the display and positioning the cursor ■ on data to be adjusted. Adjustable data, in the following descriptions of the display pages, are highlighted thus ■

By pressing these keys at the same time (or, in any event after 15 minutes) the first page appears

Site:(name)-----
FlatFr001 to 014

⊖ ⊕

Keys for :
 - adjusting the values indicated by the cursor ■
 - displaying the configuration options of a function, e.g.
 - passing directly from one menu (series of pages) to another.

Stop metering :
EXCLUDED

or

Stop metering:
SWITCH OPEN

17. NORMAL USE				
Ref.	Display	Description	Notes	Sect.
17.1	Site(nome)----- Flat Fr:001to014	Name plant site. Numbering flats.	Set in 21.1 Set in 21.2	.
17.2	New data after xx/xx/2000	The date from which the new season starts & in which have been cancelled all the partial meterings & "RECORD EVENTS"	.	13.3
17.3	Flat :001 Heat : xxxx.x	Code of flat where you want to read consumption. Heat = partial consumption heat, also called "compensated hours".	Appears only if B1 detector is "connected" in 21.4.	12.3
↓	Flat :xxx Heat :xxxx.x	<i>There follow a number of pages equal to number of flats or zones metered.</i>	.	.
17.4	Flat Central htg Heat : xxxx.x	Heat consumption in flats or zones which have not adhered to "THERMSHARE" and to radiators still centralized	Appears only if detector B1 is configured in 21.4.	12.3
17.5	Flat :001 Hours : xxxx.x	Code of flat where you want to read partial seasonal consumptions. Hours = number of hours of heat consumption.	.	12.3
↓	Flat :xxx Hours :xxxx.x	There follow a number of pages equal to number of flats or zones metered.	.	.
17.6	Flat Central htg Hours : xxxx.x	Hourly consumption for flats or zones which have not adhered to "THERMSHARE", and to radiators still centralized	.	12.3
17.7	Heating flow temp :60.0c	Heating flow temperature measured by B1 detector.	Appears only if B1 detector is "connected" in 21.4.	.
17.8	12.18 MONDAY 10.02.99 BST	Time and day of week Date and current time period: GMT or BST.	According dates BST entered in 20.1	.
17.9	Start new season? NO ->	Starting new season involves starting all the partial consumption meterings from the current date and cancelling "RECORD EVENTS" - NO: start season not requested; - YES : start season requested.	Choose "YES" then press → key to start season	13.3
17.10	Enter Access Code: ----	Enter Access Code set in: Access Code " 21.9.	Enter the code and then press → key and follow the instructions for starting the season.	13.3
17.11	Everithing read carefully? NO ->	- NO: terminate start of season; - YES : proceed with start of season	Press → key and follow instructions for carrying out start of season	13.3
17.12	Confirm start season? NO ->	- NO: terminate start of season; - YES : proceed with start of season	Press → key	13.3
17.13	New season starting...	Appears only if 17.12 is "YES".	.	13.3
17.14	New season started ->	Appears only if 17.12 is "YES".	Press → key to exit the page.	13.3
17.15	UCR 668 C1 Eng. Vers.xx	Identifying data of unit.	.	.

18. TOTAL METERING				
Ref.	Display	Description	Notes	Sect.
18.1	Flat 001: On C:00000 h:00000	Status flat 1: - On; - Off; - Fault. Total heat metering: : C : heat consumption (compensated hours); h = effective hours.	"FAULT" appears only if 21.3 is "CODED".	12.3
↓	Flat xxx: On C:00000 h:00000	There follow as many pages as there are flats or zones metered.	.	.
18.2	Flat Central htg C:00000 h:00000	Total metering of flats or zones that have not adhered to "THERMSHARE" and have remained with non-independent central heating. C : heat consumption (compensated hours); h = effective hours.	C = heat consumption, appears only if in 21.4 B1 is connected.	12.3

19. RECORD				
Ref.	Display	Description	Notes	Sect.
19.1	Flat001 Fault 1 --- of ---	Code of flat displayed From xxx to xxx at point 21.2 . 1 = progressive number of fault: from: from 1 to 3 Time, minutes and date of the fault.	+ and – keys to pass quickly to other flat codes. The most recent recording cancels the oldest one.	14.1
19.2	Flat 001 End F 1 --- of ---	Code of flat displayed:: From xxx to xxx as at point 21.2 . 1 = progressive number of fault: from: from 1 to 3 Time, minutes and date of end of fault.	Keys + and – to pass quickly to other flat codes. The most recent recording cancels the oldest one.	14.1
↓	FlatXXX Fault X --- of ---	There follows as many pages as there are flats or zones controlled.		
↓	Flat XXX End F X --- of ---			
19.1	Flat001 On 1 --- of ---	Code of flat displayed: From xxx to xxx as at point 21.2 . 1 = number of event of switching on heating from 1 to 3 Hour, minutes and date of switching on.	Keys + and – for passing quickly to other flat codes. The latest recording cancels the oldest one.	14.2
19.2	Flat001 Off 1 --- of ---	Code of flat displayed: From xxx to xxx as at point 21.2 . 1 = number of event of switching off heating from 1 to 3. Hour, minutes and date of switching off.	+ and – keys for passing quickly to other flat codes.. The most recent recording cancels the oldest one.	14.2
↓	FlatXXX On X --- of ---	For each of 14 flats there appear three pages of On and three pages of Off	All the recordings will be cancelled at the start of a new season, indicating as the first event the date of the start of the season..	
↓	FlatXXX Off X --- of ---			
19.3	On: 01 Hours: 0000 --- of ---	On: xx = varies from 1 to 16 is the progressive number of order of switching on of the devices. Hours: complete number of hours recorded at the last switching off. Time and date of last switching on.	+ and – keys for passing quickly to the other flat codes. The hour metering will be cancelled at the stat of a new season..	14.3

20. SETTING				
Rif.	Display	Description	Notes	Sect.
20.1	12.18 MONDAY 10.02.99 BST	Setting: Time, day of week & date Current time period: GMT or BST	.	
20.2	BST Fr: 31.03 to 27.10	British Summer Time (BST) period.	.	13.4
20.3	Design flow temp: 80.0	Design flow temperature.	Appears only if 21.4 is "CONNECTED".	12.2
20.4	Flow temperature Minimum Off: 25.0	Minimum flow temperature.	Appears only if 21.4 is "CONNECTED".	12.2
20.5	Auxiliary switch NORMALLY CLOSED	"Auxiliary" control switch: NORMALLY CLOSED, NORMALLY OPEN.	NORMALLY CLOSED: switch open when auxiliary control is switched on; NORMALLY OPEN: switch closed when auxiliary control is switched off;	12.5
20.6	Aux : AUTOMATIC Delay On: --Off: 30	Auxiliary control: ALWAYS ON; AUTOMATIC Delay in switching on and off.	ALWAYS ON: auxiliary control always On; AUTOMATIC: auxiliary control On only if at least one flat or zone calls for heat, or in event of fault.	12.5
20.7	Stop metering : EXCLUDED	Stop metering by switch "F" : EXCLUDED ; SWITCH OPEN; SWITCH CLOSED.	.	12.4
20.8	Boosted heating for hours : 1	Period of boosted heating (valve open) started by switches k1...kn.	.	12.6

21. CONFIGURATION METERING UNIT

Ref.	Display	Description	Notes	Sect.
21.1	Name plant site -----	Entering name plant site.	Use + and – keys to enter letters or numbers. Use ← and → keys to change cursor position.	13.2
21.2	Flat code Fr:001 to:014	Codes of flats connected. Take great care to number correctly since on this depends the correct allocation of all the heating costs.	.	12.1
21.3	Input meters CODED	CODED = UCR 668 is connected in "THERMSHARE" system to ICS 6.. units. ON - OFF = UCR 668 is connected to a normal voltage-free closure switch ? which can derive from the organ providing the heating.	= "THERMSHARE" plant. = zoned plant	13
21.4	Flow T detector CONNECTED	CONNECTED = when it exists & is connected. NOT CONNECTED = when does not exist.		13
21.5	Recordings EVERY WEEK	Setting frequency of recordings: EVERY HOUR = intervals of an hour between recordings. EVERY DAY = intervals of a day between recordings. EVERY WEEK = intervals of a week between recordings	The daily or weekly recordings take place at 0.00 hours.	14.4
21.6	Send Alarms :NO PassWTeleman :NO	Enabling alarms to send to telemanagement PC. Enabling telemanagement password.	Necessary only if connected in C-Bus.	10.4
21.7	Address : --- Group : -	Telematic address of controller Group to which controller assigned	Only if connected in C-Bus.	10.3
21.8	Various alarms - 2 7 8	Alarms 7 and 8 cannot be disabled.	Use + and – to enable or disable the sending of an alarm. Use ← and → to change position of cursor. 1 : Flow detector B1. 2 : Alarm for fault in flats. 7 : Data storage alarm. 8 : Internal clock alarm.	13
21.9	Access code ----	Choice code for preventing use + and – keys. The code can be alphanumeric.	Use + and – to enter letters or numbers Use ← and → to change position cursor..	13.1

22. TESTING

Ref.	Display	Description	Notes	Sect.
22.1	Output : BOOSTING Status : OFF	Choice output to test : – BOOSTING – AUX – FAULT Choice output status : – OFF = Output Off.. – ON = Output On.		15.1

Amendments to data sheet

Data	Revisione n.	Pagina	Paragrafo	Descrizione modifiche	Versione Firmware	Versione Software
09.02.07 SD		3 8	8. WIRING 11.4 TRADITIONAL ZONED PLANT..	Section amended and summary tables added. Added operational diagram for siting switchboards below stairs/in cellar or in boiler house.		
22.04.11 VM	01	1		Note about UNI / TR 11388 certification		



Head Office & Sales

Via San G.B. De La Salle, 4/a Tel. +39 022722121
20132 - Milano Fax +39 022593645
Orders Fax +39 0227221239
Reg. Off. Central & Southern

Via S. Longanesi, 14 Tel. +39 065573330
00146 - Roma Fax +39 065566517

Shipping

Via Gen. Treboldi, 190/192 Tel. +39 0364773200
25048 - Edolo (BS) Tel. +39 0364773202

E-mail: info@coster.info Web: www.coster.eu



D 33214